

# AutoFresh™ Aerosol

## Service Dispenser




### INSTALLATION INSTRUCTIONS

## MOUNTING & OPERATING INSTRUCTIONS

### WALL MOUNTING:

For effective operation, mount dispenser above eye level, a minimum of 7 feet (2.2m) from floor to bottom of dispenser. Ensure location is where moving air will disperse the Neutrale Metered Aerosol throughout the entire area. Position dispenser over wall stud and secure with the supplied screws (2 screws). One AutoFresh™ Aerosol Dispenser treats up to 6,000 cubic feet (170m<sup>3</sup>).



## AUTOFRESH™ AEROSOL SERVICE DISPENSER OPERATING INSTRUCTIONS:

1. Open AutoFresh™ Aerosol Service Dispenser cover with provided key.
2. Insert two "D" cell alkaline batteries - unit is now on, yellow light flashes. Change batteries when light stops flashing.
3. Select the intensity & duration of the air neutralizer:
  - 30 - operates 24 hours-a-day for 30 days
  - 45 - operates 24 hours-a-day for 45 days
  - 60 - operates 24 hours-a-day for 60 days
4. Stand to the side of the dispenser to avoid being sprayed in the face; place a Neutrale Metered Aerosol into dispenser.
5. Close the AutoFlush™ Aerosol Service Dispenser cover.

**CAUTION:** Never stand directly in front of dispenser when the unit is on to avoid being sprayed in the face.



Technical Concepts L.P.  
World Headquarters:  
1301 Allanson Road  
Mundelein, Illinois 60060  
U.S.A.  
☎ 1-800-551-5155  
Fax: 1-800-551-5046

Technical Concepts International Ltd.  
European Headquarters:  
Pin Green Business Park Eastman Way  
Stevenage, Herts SG1 4UH, England  
☎ +44 (0)870 568 6824  
Fax: +44 (0)1438 311200

Technical Concepts Asia  
Malaysia Headquarters:  
51 (B) Lorong Perindustrian Bukit minyak 9  
14100 Bukit Mertajam  
Penang, Malaysia  
☎ (60) 4 508 5008  
Fax: (60) 4 508 5001

Toll Free: 1-800-551-5155

Web: [www.technicalconcepts.com](http://www.technicalconcepts.com)

Email: [info@technicalconcepts.com](mailto:info@technicalconcepts.com)